

DATE: 12-05-2000

FIG. 1




FIG.2




FIG.3

| SWITCH A | SWITCH B | SWITCH C | SWITCH D | LIGHT EMISSION | PEN DOWN | PEN BUTTON |
|----------|----------|----------|----------|----------------|----------|------------|
| x | x | - | - | OFF | OFF | OFF |
| 0 | x | x | x | ON | OFF | OFF |
| 0 | x | 0 | x | ON | ON | OFF |
| 0 | x | x | 0 | ON | OFF | ON |
| 0 | x | 0 | 0 | ON | ON | ON |
| 0 | 0 | - | - | ON | ON | ON |
| x | 0 | - | - | ON | ON | OFF |

FIG. 4




FIG.5




FIG.6




FIG.7




FIG.8



004120-12052560

FIG.9




FIG.10






FIG.11



00525021 021400 004720 12052500

FIG.13



004120 12052560

FIG.14A




FIG.14B




FIG.15




FIG.16




FIG.17




FIG.18




FIG.19




FIG.20




FIG.21A




FIG.21B




FIG.21C




FIG.22




FIG.23




FIG. 24




FIG.25

